


RAC1HD Firmware Update Install Guide

1. DOWNLOAD FIRMWARE UPGRADE

Periodically firmware updates will become available. To download the latest version of firmware visit: www.clintonelectronics.com

- 1.1.** Remove the microSD card from the camera and insert into a computer with the included USB adaptor.
- 1.2.** Back-up important videos to a computer before upgrading the firmware.
- 1.3.** Format the microSD card prior to upgrading the firmware.
- 1.4.** Copy the firmware update to the top/root folder on the microSD card. Then eject the microSD card from the computer.




COPY FIRMWARE
UPDATE HERE

2. UPGRADE FIRMWARE

- 2.1.** With the firmware update saved to the microSD card, insert the microSD card back into the camera (with the power turned OFF).
- 2.2.** Turn the power ON to the camera. Shortly after the camera has booted up, you will be prompted with an audio message of "Upgrade File Prepared."
- 2.3.** Press and Hold the MIC/FCN button (for approximately 5 seconds) until you hear "Starting the Upgrade." The REC LED will flash Red and Blue during the upgrade. Do not detach the power cable or turn off vehicle while the firmware upgrade is taking place. Doing so could cause damage to the firmware of the camera.
- 2.4.** The camera will restart after successfully upgrading.

Wireless firmware updates via the phone app will be supported in the future.



LED FLASHES
RED & BLUE